



[Adobe PDF Downloadable Version of Article](#)



1) Insert the sling as shown in figure 1.



2) Loop back around and slide under the sling's loop.

3) Figure 3 shows how the sling should look.



4) Next slide the sling through the adjustable keeper.

5) Slide the end of the sling with holes through the butt stock.



6) Figure 6 shows the keeper (Frosch) and the direction it should be installed.

7) Slide the sling through the keeper and over the stud.



8) Push the stud up through the desired hole in the sling.

9) Figure 9 shows the keeper sitting properly in the butt stock.



10) Adjust the sling to what works for you.

11) Figure 11 shows the completed installation of the 98k/Yugo m48 sling.



[Adobe PDF Downloadable Version of Article](#)